

EFTPOS Now.

A Quick Reference Guide to help you
get started with your terminal.

This simple guide gives you all the basic steps to set up and use your terminal to start accepting payments.

Getting Started.

























How to turn on your terminal.



Hold the Power button down for approximately 3 seconds until the terminal turns on.

Terminal layout.



Navigation icons and keys.

Status icons	Notification icons	Navigation keys
 Bluetooth enabled	 Warning/Attention	 Recent apps
 Bluetooth enabled, connected to base	 Important information	 Home/Payment app
 Aeroplane mode	 Download/Update in progress	 Back
 Mobile signal	Quick settings icons	 Menu
 Wi-Fi	 App launcher	 More options
 SIM Card	 Torch	 Expand
 Battery charging	 Auto rotate	 Collapse
 Battery level	 Edit	 Add reference
	 Settings	

Important: You can return to the payment screen at any time by pressing the Back  and/or Home  keys.

How to load a paper roll.



- 1 Open the paper roll compartment by holding the terminal base securely and lifting the sides of the paper compartment door upwards and back.
- 2 Place a paper roll in the compartment. Ensure that the paper end is feeding under the roll and towards the terminal screen, as shown above.
- 3 Hold the paper and then close the compartment door until it clicks securely back into position.

Important: The paper roll is thermal-sensitive and will only print on one side.

How to activate your terminal.

If your terminal has been installed by a technician, it will already be activated ready for use.

If your terminal has been sent to you (via satchel), you'll need to activate it before you can use it.

Please call the Merchant Helpdesk to activate your terminal.


1300 130 190 (available 24 hours a day, 7 days a week).

Terminal Communication.

Wi-Fi.

Wi-Fi can be set up from the Status Bar at the top of the touch screen or through the Android Settings.

To access the Wi-Fi settings from the Status Bar

- 1 Swipe down from the top of the screen to view the status icons.
- 2 Press and hold the Wi-Fi icon . The Wi-Fi settings will open.
- 3 Turn Wi-Fi On and select the relevant network from the available Wi-Fi networks.
- 4 Enter the network password and select **CONNECT**.

Processing a Transaction.

Purchases.



Insert



Swipe



Tap

- 1 From the amount-entry screen, use the touch screen to enter the purchase amount, e.g., \$25 = 2500.
- 2 Select **Purchase**.
- 3 The cardholder may tap, insert, or swipe their card; or tap their payment-enabled smart device.
- 4 If the cardholder has inserted or swiped their card, they will be prompted to select their account type.
- 5 The cardholder will be required to enter their PIN or sign (if required) to complete the transaction.
- 6 If a signature is required, the cardholder must sign using their finger directly on the touch screen.
- 7 Select **Yes, Approve** to confirm that the signature matches the signature on the back of the card; or select **No** to cancel the transaction.
- 8 Keep the merchant copy of the receipt for your records.
- 9 The terminal will prompt for a customer copy of the receipt to be printed or emailed.

Important: Always check the receipt to confirm the transaction has been approved before completing the transaction. Retain your copy of the terminal receipts for a minimum of 18 months.

Refunds.

- 1 From the amount-entry screen, use the touch screen to enter the refund amount, e.g., \$25 = 2500.
- 2 Select **Other**.
- 3 Select **Refund**.
- 4 Enter the Manager passcode.
- 5 Select **Card or Mobile**.
- 6 The cardholder may tap, insert, or swipe their card; or tap their payment-enabled smart device.
- 7 If the cardholder has inserted or swiped their card, they will be prompted to select their account type.
- 8 The cardholder will be required to enter their PIN and/or sign (if required) to complete the transaction.
- 9 If a signature is required, the cardholder must sign using their finger directly on the touch screen.
- 10 Select **Yes, Approve** to confirm that the signature matches the signature on the back of the card; or select **No** to cancel the transaction.
- 11 Keep the merchant copy of the receipt for your records.
- 12 The terminal will prompt for a customer copy of the receipt to be printed or emailed.

Important: Always check the receipt to confirm the transaction has been approved before completing the transaction. Retain your copy of the terminal receipts for a minimum of 18 months.

Settlement Totals.

Settlement is the process that's completed so you can be paid for your transactions.

Auto settlement.


The terminal will automatically settle every day at your nominated auto settlement time. A default auto settlement time will be assigned if you haven't chosen an auto settlement time.

The terminal must be turned on to complete an auto settlement. If your terminal can't complete an auto settlement, we'll conduct the settlement on your behalf.

If you wish to change your auto settlement time, contact the Merchant Helpdesk.


Manual settlement.

You may perform a manual settlement at any time throughout the day – before the auto settlement occurs. However, settlements can't be processed between 9:30 pm and 11:00 pm (Sydney time).


- 1 Select the menu icon  located at the top left of the amount-entry screen.
- 2 Select **Settings**.
- 3 Select **Account**.
- 4 Select **Settlement**.
- 5 Select **Settle Now**, this will trigger the manual settlement.
- 6 The settlement report will be displayed on the screen and printed.

Important: You can only perform a settlement once a day, before 9:30 pm (Sydney time). A settlement done after 11:00 pm will be processed as a settlement for the next day.

Settlement history.

- 1 Select the menu icon  located at the top left of the amount-entry screen.
- 2 Select **Reports**.
- 3 Select **Settlement History**.
- 4 Select the required date.
- 5 The requested settlement will be displayed on the screen. Select **Print**, if required.


Settlement enquiry.

- 1 Select the menu icon  located at the top left of the amount-entry screen.
- 2 Select **Reports**.
- 3 Select **Settlement Enquiry**.
- 4 The current settlement totals (since your last settlement) will be displayed on the screen. Select **Print**, if required.

Transaction Reports.


Reprint receipt.

You can search, view, reprint or email receipts for transactions processed in the past 14 days. A transaction may also be referred to as an Order.

- 1 Select the menu icon  located at the top left of the amount-entry screen.
- 2 Select **Transaction History**.
- 3 The Transaction History will be displayed and organised by transaction date and time.
- 4 You can scroll up and down the screen to locate the required transaction.
- 5 Select the required transaction.
- 6 Select **Receipt**.
- 7 Select **Merchant Copy**, **Customer Copy** or **Email Receipt**.


Transaction history.

You can view or print a history of your transactions for the past 14 days.

- 1 Select the menu icon  located at the top left of the amount-entry screen.
- 2 Select **Transaction History**.
- 3 The Transaction History will be displayed and organised by transaction date and time.
- 4 You can scroll up and down the screen to locate the required date.
- 5 Select the printer icon next to the required date to view an expanded transaction history for that day.
- 6 Select **Print** if required.

Transaction search.

You can search transactions using advanced search options.

- 1 Select the menu icon  located at the top left of the amount-entry screen.
- 2 Select **Search Transactions**.

There are 3 ways a search can be performed.

1 Search bar

- Enter the last 4 digits of the card, or the full STAN in the search bar. STAN is a six-digit ID number found on the receipt.
- All transactions that meet the search criteria will be displayed.
- Select the required transaction.
- Select **Receipt**.
- Select **Merchant Copy, Customer Copy** or **Email Receipt**.

2 Card search

- Select the card icon in the search bar.
- Tap, insert or swipe the card to start the search.
- Select the required transaction.
- Select **Receipt**.
- Select **Merchant Copy, Customer Copy** or **Email Receipt**.

3 Advanced search

- Select **Advanced Search**.
- Search criteria includes amount, date range or transaction type and more.
- Use the onscreen keypad to enter the values.
- Press the green arrow to move to the next field.
- Press the green tick to finish entering the search criteria.
- Select **Search**.
- Select the required transaction.
- Select **Receipt**.
- Select **Merchant Copy, Customer Copy** or **Email Receipt**.


Passcodes.

Your terminal has the ability to limit and protect transactions and functionality such as refund, MOTO (Mail Order and Telephone Order), settlements and more, by using passcodes. The passcode levels available are Manager and Cashier.

Change your passcodes.



Use this process if you need to change your Manager passcode or change or reset your Cashier passcode.

Important: The current Manager passcode is required to change both the Manager passcode and the Cashier passcode.

- 1 Select the menu icon  located at the top left of the amount-entry screen.
- 2 Select **Settings**.
- 3 Select **Security**.
- 4 Enter the current Manager passcode and press **Enter**.
- 5 Select **Passcode management**.
- 6 Select **Manager** or **Cashier**.
- 7 Enter the Manager passcode and press **Enter**.
- 8 Enter the new Manager or Cashier passcode and press **Enter**.
- 9 Re-enter the new Manager or Cashier passcode and press **Enter**.

Reset your manager passcode.

Use this process if you've forgotten your Manager passcode.

- 1 Select the menu icon  located at the top left of the amount-entry screen.
- 2 Select **Settings**.
- 3 Select **Security**.
- 4 Select the More options icon  at the top right of the screen.
- 5 Select **Switch to Admin**.
- 6 Contact the Merchant Helpdesk to get the current Admin passcode.
- 7 Enter the Admin Passcode and press **Enter**.
- 8 Enter the new Manager passcode and press **Enter**.
- 9 Re-enter the new Manager passcode and press **Enter**.

Troubleshooting.

Hardware Faults	Action
Blank Screen – the terminal isn't turning on.	<ol style="list-style-type: none">1. Ensure that the battery charge state is not below the critically low level. The terminal will not work if there is insufficient charge remaining in the battery.2. Connect the terminal to a power source for at least 5 minutes.3. Hold the power button down for approximately 3 seconds until the terminal turns on.4. If the problem persists, call the Merchant Helpdesk.
The touch screen isn't responding.	<ol style="list-style-type: none">1. Turn off the terminal for 10 seconds.2. Turn the terminal on again.3. Retry the transaction.4. If the problem persists, call the Merchant Helpdesk.
Paper jam or printing errors.	<ol style="list-style-type: none">1. Remove the paper roll from the compartment to check that there's no paper caught.2. If the existing paper roll is damaged in any way, replace it with a new roll.3. Paper rolls are thermal-sensitive and will only print on one side. Make sure the paper roll is loaded correctly.4. Check that the paper compartment door is closed securely.5. If the problem persists, call the Merchant Helpdesk.

Any questions? Just ask.

Merchant Support Centre and Order Stationery Online

banksa.com.au/merchantsupport

Merchant Helpdesk

Service, Sales and Support, Terminal Difficulties, Stationery Orders.

1300 130 190 (available 24 hours a day, 7 days a week).

Handy hint: Have your Merchant and Terminal numbers ready so we can assist you promptly.

banksa.com.au/eftposnow

Credit Card Authorisation

1300 301 831

